

Using the remote control


Remote control paired devices

When the device is in the standby state (not rotating), click the "MATCH" button on the back of the device (click the "ALL" button on the remote control to enter this state), the indicator light changes from red to green flashing, and then use the remote control to pair. When the device is ready, click the "MATCH" button on the remote control, and the indicator light flashes green quickly and then returns to red, which means the pairing is successful. After pairing, refer to: the description of each button on the remote control to control the device.

Note:

- 1) One remote control can be paired with multiple devices, so that multiple devices can be controlled at the same time through one remote control.
- 2) One device can only be controlled by one remote control. The last paired remote overrides previously paired remotes.

Description of remote control buttons



- | | |
|---|---|
| 1 ON: Device rotary switch | 9 P-: switch to previous video |
| 2 OFF: Device stop switch | 10 RESET: reboot the system |
| 3 P1: Back to first video | 11 WIFI: turn on wifi |
| 4 L+: increased brightness | 12 WIFI : turn off wifi |
| 5 P+: switch to next video | 13 C: Enter cloud mode |
| 6 ALL: All hosts enter the matching remote control state | 14 A: Disconnect from cloud and outed mode |
| 7 MATCH: match remote control | 15 R: enter routing mode |
| 8 L- : reduce brightness | |